

























































































**IT:** Tabelle di corrispondenza tra il telecomando Meliconi e la configurazione selezionata  
**FR:** Tableaux de correspondance entre la télécommande Meliconi et la configuration sélectionnée  
**GB:** Tables of correspondence between the Meliconi remote control and the selected configuration  
**DE:** Tabellen der Übereinstimmung zwischen der Meliconi-Fernbedienung und der gewählten Konfiguration  
**ES:** Tablas de correspondencias entre el mando a distancia Meliconi y la configuración seleccionada  
**PT:** Tabelas de correspondência entre o controlo remoto do Meliconi e a configuração selecionada

<b>EASY 100</b>	<b>1</b>
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
	
PRE CH	P/P
	
	
P 	P 
P 	P 
	<b>NETFLIX</b>
	RAKUTEN TV
	<b>PRIME VIDEO</b>
MENU	MENU
GUIDE	GUIDE
BACK	BACK
EXIT	EXIT
	
	
	
	
	
	
INFO	INFO
	
	
	
	
	
TOOLS	TOOLS
	
	
	
	
	
	
	
	

<b>EASY 100</b>	<b>2</b>
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
	
PRE CH	P/P
	
	
P ^	P ^
P v	P v
	<b>NETFLIX</b>
	RAKUTEN TV
	<b>PRIME VIDEO</b>
MENU	MENU
GUIDE	GUIDE
BACK	BACK
EXIT	EXIT
	
	
	
	
	
	
INFO	INFO
	
	
	
	
	
TOOLS	TOOLS
	CH LIST
	SUBT
	P.SIZE
	
	P.MODE
	S.MODE
